

INSTALLATION/EXCAVATION TIPS

ADD 5% TO OUTER PLAN DIMENSIONS WHEN EXCAVATING PIT.
ALWAYS CHECK PIT DIMENSIONS AT BASE OF PIT, ENSURING SIDES ARE

LEVEL AND SCREED DRAINAGE LAYER PRIOR TO PLACEMENT OF CELLS.

ALLOW FOR EASE OF INSTALLATION OF OVERALL MATRIX.

NOTE: ADEQUATE DRAINAGE FROM BASE OF TREEPIT TO BE
PROVIDED IF DESIGN INCORPORATES WSUD PRINCIPLES, OR IF
SITE CONDITIONS REQUIRE.



No.	Revision:	Date:	ľ
			L
			Н

Designed: Checked: 03/19/12 AS SHOWN

LINKED TREEPIT W/OPEN SURROUND 1.8m3/m **DETAIL PLANS**

Rev. A Drawing No.