





COMPONENT LIST	
PRODUCT	QTY
SC250 StrataCell STRUCTURAL SOIL CELL	VARIABLE
FG3030 FilterGrid BI-AXIAL FILTER LAYER	VARIABLE
RRPREC1 RootRain CIVIC SINGLE INLET	VARIABLE
RRARB2 RootRain ARBORVENT DUAL INLET	VARIABLE
RER300 ReRoute LINEAR RIBBED R/BARRIER	VARIABLE
RS1000 RootStop BARRIER	VARIABLE



LINKED TREEPIT - TOP VIEW



LINKED TREEPIT - SECTION BB

NOTE : ENSURE THE PIT BASE IS SCREEDED AND LEVELLED PROPERLY BEFORE PLACING CELLS ON BASE, TO ALLOW FOR EASE OF INSTALLATION OF OVERALL MATRIX.
NOTE : ADEQUATE DRAINAGE FROM BASE OF TREEPIT TO BE PROVIDED IF DESIGN INCORPORATES WSUD PRINCIPLES, OR IF SITE CONDITIONS REQUIRE.

DISCLAIMER
All foundation details to be verified by a qualified engineer. The manufacturer disclaims liability resulting from any loss or damage incurred from their products, or their installation method, either direct or consequential.
Designed: JS Checked: -
Date: 03/19/12 Approved: -
Scale: AS SHOWN



No.	Revision:	Date:

Title	
LOW-IMPACT DEVELOPMENT	
DETAIL PLANS	
Drawing No.	Rev. A

- INSTALLATION/EXCAVATION TIPS
1. ADD 5% TO OUTER PLAN DIMENSIONS WHEN EXCAVATING PIT.
 2. ALWAYS CHECK PIT DIMENSIONS AT BASE OF PIT, ENSURING SIDES ARE CLEAN AND SQUARE.
 3. LEVEL AND SCREED DRAINAGE LAYER PRIOR TO PLACEMENT OF CELLS.